

JASPI J-Immersion  
 3.3, 4.5 or 6kW  
 230VAC  
 Single or triple phase


Install the immersion to the upper part of the thermal store if it is to be used for domestic hot water boost / back-up only.



1

2

If the immersion is used to back-up the heating and hot water, install it to the lower part of the store. Some thermal stores have couplings for several immersions. This is more preferable if a cheaper electricity tariff / night time charging is used.



<b>JASPI UK</b> <a href="http://www.jaspi.co.uk">www.jaspi.co.uk</a>			
Jaspi J-Immersion heater thermal store locations			
Drawn	Version	Date	Drawing Ref
SS		01.03.2012	Generic