


Expansion vessel.
 Must always be used when the store is pressurised.
 Recommended size 50L or minimum of 7% of the total capacity of the heating system, including the pipework and radiators.
 Vessel pre-pressure 1.4 - 2.0 bar must always be checked before commissioning.



IT IS ESSENTIAL THAT THESE SAFETY DEVICES ARE FITTED TO THE ULTRASTORE ACCUMULATORS PRIOR TO FILLING UP AND COMMISSIONING. THE FUNCTIONING OF THE PRESSURE RELIEF VALVE(S) MUST BE CHECKED REGULARLY.

JASPI UK www.jaspi.uk			
Ultrastore 500 Essential safety devices			
DRAWN	VERSION	DATE	DRAWING REF.
SS		25.10.2014	Generic